

Installation

- Before starting installation make sure the sub floor is permanently dry and free of dirt, dust, grease and other foreign matter.
- Correct any open cracks and fill with a high-grade patch. Sub floor should be properly leveled.
- Roll out and position the first row of Floor acoustic underlayment with the vapour barrier surface facing downwards, allowing the pad to run up exterior walls 1/2".
- Install the floor covering per manufactures written instructions.
- Roll out the second row of underlay near the edge of the first row of underlay and be sure to align the edges of the first and second rows as tightly as possible, both side by side and end by end (do not overlap the underlays). You can tape the seams, but it is not necessary.
- Continue installing in the same manner until the installation is complete.
- Trimming excess underlayment is necessary to allow for baseboard or quarter round installation and be sure the Installed baseboard slightly off floor to avoid the transferring of noise by ground vibrations to the wall.